

CAYIN Signage Player Installation Guide - Samsung TV

1. Installation File Location and Preparation

① File Download:

Please download the installation file from the CAYIN official website.


② Folder Content Description:

userwidget\

|— CayinSignagePlayer.tmg

|— widget.license

Please make sure to keep both the **CayinSignagePlayer.tmg** and **widget.license** files intact in the **userwidget** folder.



③ Update Instructions:

If you are performing a version update, simply replace the original **userwidget** folder with the new one.


2. Samsung TV Settings

① Set Playback Source:

Go to the TV settings page and follow the path below:

Settings>All Settings>System>Play via>Custom App

Please set “**Play via**” as “**Custom App**”.



② App Configurations:

On the App page, please enter **12345** > **Confirm Developer mode: Off** ;

Local mode: Off




3. Install App via USB

① Insert USB Device:

Insert the USB flash drive containing the **userwidget** folder into the TV's USB port.


② Automatic Installation:

The TV will automatically detect the **userwidget** and begin installing the app.



4. Items to Confirm After Installation

- 1 Check if the app appears successfully on the TV home screen.



- 2 Verify whether you can smoothly enter the app and display the screen.



- 3 Confirm if the version and features are up to date.